



(EN): Press here for lights & sounds
(FR): Appuie ici pour activer les lumières et les sons
(DE): Drücke hier für Lichter und Geräusche
(ES): Presione aquí para luces y sonidos
(IT): Premere qui per luci e suoni




(EN): Push the car to move it forward
(FR): Pousse la voiture pour la faire avancer
(DE): Schiebe das Auto, um es vorwärts zu bewegen
(ES): Empuje el coche para moverlo hacia adelante
(IT): Spingere la macchina per spostarla in avanti



⚠ WARNING: This product contains Button or Coin Cell Battery.
A swallowed Button or Coin Cell Battery can cause internal chemical burns leading to death in as little as two hours. Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

REPLACING BATTERIES / REMPLACEMENT DE PILES BATTERIEN AUSWECHSELN / CAMBIO DE PILAS / SOSTITUZIONE BATTERIE



Close
En arrêt
Schließen
Cerrado
Spento

Open
En marche
Öffnen
Encendido
Acceso



(EN): WARNING: SMALL PARTS - CHOKING HAZARD. Not suitable for children under 3 years.
(FR): ATTENTION: PETITS ÉLÉMENTS - DANGER D'ÉTOUFFEMENT. Ne convient pas aux enfants de moins de 3 ans.
(DE): ACHTUNG: KLEINE TEILE - ERSTICKUNGSGEFAHR. Nicht für Kinder unter 3 Jahren geeignet.
(ES): ADVERTENCIA: PIEZAS PEQUEÑAS - PELIGRO DE ATRAGANTAMIENTO. No apropiado para niños menores de 3 años.
(IT): AVVERTENZA: RISCHIO DI SOFFOCAMENTO DI PICCOLE PARTI. Non adatto a bambini di età inferiore a 3 anni.
(NL): WAARSCHUWING: KLEINE ONDERDELEN - VERSTIKKINGSGEVAAR. Niet geschikt voor kinderen jonger dan 3 jaar.
(DK): ADVARSEL: SMÅ DELE - FARE FOR AFKØKNING. Ikke egnet til børn under 3 år.
(SE): VARNING: KVÄVNINGSRISIK - Små delar. Inte för barn under 3 år.
(PL): OSTRZEŻENIE! MAŁE ELEMENTY - NIEBEZPIECZENSTWO ZADŁAWIENIA. Nieodpowiednie dla dzieci w wieku poniżej 3 lat.
(GR): ΠΡΟΣΟΧΗ! ΚΙΝΔΥΝΟΣ ΠΝΙΓΜΟΥ - Περιέχονται Μικρά Μέρη. Δεν είναι κατάλληλο για παιδιά ηλικίας κάτω των 3 ετών
(AR): تحذير: خطر الاختناق لأن المنتج يحتوي على أجزاء صغيرة. لا يناسب الأطفال دون 3 سنوات

⚠ WARNING:
CHOKING HAZARD—Small parts.
Not for children under 3 years.

⚠ WARNING:
Contains Button or Coin Cell Battery.
Hazardous if swallowed—see instructions.

⚠ AVERTISSEMENT:
RISQUE DE SUFFOCATION—Petites pièces.
Ce produit n'est pas recommandé pour les enfants de 3 ans et moins.

⚠ AVERTISSEMENT:
Contient une pile bouton. Dangereux en cas d'ingestion—voir les instructions.

WH1257/WH1257Z

